Temperature sensors for Hazardous Areas

INTRINSICALLY SAFE TEMPERATURE SENSORS



Catalogue | Edition 2023

RESISTANCE THERMOMETER

Type XI-TOPGB, XI-APTOPGB

The sensor consists of an exchangeable measuring insert, outer protective tube (thermowell) and aluminum connection head where mounting a temperature transmitter with 4-20 mA/HART® output signal is possible.

The measuring insert represents the replaceable element of the complete sensor which reduces time and costs of maintenance of the measuring apparatus installed in the object. Spring fixation of the measuring insert provides perfect pressure to the bottom of the protecting tube, reduces time of reaction to changes of temperature and increases accuracy of measurement as well as reduces natural vibration thus mechanical and electrical defects can be avoided.

TECHNICAL DATA

Description

- intrinsically safe for mines M1, gas G and dust D atmospheres
- •single and double RTD
- exchangeable mineral insulated measuring insert
 connection head types: XE-DANA (G1); XE-DANAW (G2);
 XE-DAND (G5); XE-DANDW (G6); XE-BE (E1); XE-BED (E2); IP65; ATEX II 2 GD (see technical information)

 •process connection: M20xl.5 or G1/2" welded-in to the thermowell*
- •cable gland ATEX I M1, II GD, IP65; (cable dia. 5..10mm)*
- •output signal: RTD or 4-20mA (option)

Design temperature range

-200 .. +150°C

sei	ising element	

acc. to EN 60751 class A, B lx or 2xPt100

Thermowell	
Material	stainless steel 1.4541*
Diameter D [mm]	Ø9, Ø11, Ø12, Ø15 or other*
Length L [mm]	100, 160, 200, 250, 400, 500 or other*


Temperature transmitter (option)

PR5333D, PR5335D (HART®) FlexTop2202, FlexTop2212, FlexTop2222 (HART®)

Remarks

* other parameters on request

ATEX Marking:	EAC Ex Marking:
C€ I M1 Ex ia I Ma	PO Ex ia I Ma X
CE ■ 11/2 G Ex ia 11 C T Ga/Gb	0Ex ia IIC TGa X
CE II 1/2 D Ex ia IIIC T Da/Db	0Ex ia IIIC TDa X





Thermowell GB with process connection (tapered thread)


•	Н
1	th
	th

Handtight engagement	Dimension K
thread 1/2"NPT	8.1 mm
thread 3/4"NPT	8.6 mm

Connection head (variants)















Temperature sensors for Hazardous Areas

INTRINSICALLY SAFE TEMPERATURE SENSORS

Catalogue | Edition 2023

Temperature transmitter can be mounted inside a connection head of the sensor. There are two mounting options: directly on the measuring insert or in a high cap of the head. Advantage of the second solution is an easy replacement of the standard insert with a terminal block without need to dismantle the transmitter, which significantly reduces a time and cost of servicing the sensor and protects the connecting wires from damage. At the customer's request, it is possible to mount two transmitters. Temperature transmitter should be protected from temperatures over +85°C.



